

UTTERMOST

ASSEMBLY INSTRUCTIONS

Assembly Instruction

STYLE NO:18102

1. Take the parts carefully out of the carton, and place it on a flat surface, make sure that the parts will not be damaged.
2. Place the white rice stone (A) onto the Screw bolt of ASSEMBLY "B" properly.

