

UTTERMOST

ASSEMBLY INSTRUCTIONS

THANK YOU FOR PURCHASING THE FLOOR LAMP .
PLEASE FOLLOW THE INSTRUCTIONS LISTED BELOW:

ASSEMBLY INSTRUCTIONS: MODEL NUMBER: 30561

1. UNPACK ALL PARTS FROM CARTON CAREFULLY.
2. PLACE LAMP BODY (A) INTO THE HOLE IN THE BASE (B).
3. ATTACH THE LAMP BODY TO THE BASE USING WASHER (C), NUT (D) ON THE UNDERSIDE OF THE BASE. TIGHTEN WITH THE PROVIDED SPANNER (E).
4. USE TWO SCREWS (F) ON THE UNDERSIDE OF THE BASE TO SECURE THE LAMP BODY IN PLACE. TIGHTEN USING THE PROVIDED ALLEN WRENCH (G).
5. PLACE THE SHADE (I) ONTO THE SOCKET (H) AND SECURE WITH THE SOCKET RING (J). BE SURE THE RING IS ATTACHED CORRECTLY TO AVOID CROSS THREADING.
6. INSTALL BULB (K) INTO THE SOCKET.
7. ASSEMBLY IS COMPLETE.

IMPORTANT SAFETY INSTRUCTION:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER).
AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK, THIS PLUG WILL
FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT, REVERSE THE PLUG.
IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN.
NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED.
DO NOT ALTER THE PLUG.

