










Assembly Instructions

SKU# 51031698

PARTS LIST

A	TABLE TOP X1						<p>Before beginning</p> <p>1) Carefully unpack and position the item on a clean, non-marring surface to assemble.</p> <p>2) Read this Assembly Instructions from beginning to end before starting to assemble.</p> <p>3) Take an inventory of the required parts to ensure all are available.</p> <p>4) To prevent accidental choking hazards, keep all packing materials away from small children.</p> <p>5) Only tighten hardware until ALL hardware are fully engaged on their locations. Overtighten bolts will damage the bolt threads.</p> <p>6) Use only factory provided hardware to assemble. Unapproved hardware can damage product or jeopardize the structural integrity of the product.</p> <p>7) The use of power tool to assemble is not recommended due to high risk of over-torque, which can damage the product.</p>
							
							
D	HARDWARE	Z 1	Z 2	Z 3	Z 4	Z 5	
							
		M8x20mm X 4	M8x25mm X 4	Ø12x1.5mm X 4	Ø30x2.0mm X 4	M4x60mm X 1	



ASSEMBLY REQUIRES
TEAM PEOPLE



20 MINUTE
ASSEMBLY TIME




KEEP INSTRUCTIONS
FOR FUTURE USE




Assembly Instructions

CARDERNA DINING TABLE

1



2



Tighten individual screw at 50%, and only fully tighten when screws are all in place.

Assembly Instructions

CARDERNA DINING TABLE

3

