


UTTERMOST

ASSEMBLY INSTRUCTIONS

Assembly Instruction

STYLE: 50156

Parts List		Hardware List		
A	GLASS TOP	1PC	SCREW (size: M6X15MM)	16PCS
B	GLASS SHELF	1PC	ALLEN WRENCH	1PC
C	TOP FRAME	1PC		
D	SHELF FRAME	1PC		
E	BAR CART LEG	4PCS		



1.) Carefully remove all parts from the carton and place on a soft, flat surface to be sure no parts are damaged or missing.

2.) Use the provided Wrench and 4 SCREWS to attach one LEG (E) to both the TOP FRAME (C), SHELF FRAME (D). Do not fully tighten the screws until Step 3.

3.) Repeat Step 2 until all legs are attached. Once all legs are attached to the shelf frame, fully tighten all screws.

4.) Place GLASS TOP (A) into TOP FRAME (C) and GLASS SHELF (B) into SHELF FRAME (D).

5.) To clean, wipe with soft dry cloth. Assembly is complete.